

# FOOD PAN SIZES

**FULL**  
**20 3/4" X 12 3/4"**  
2 1/2" Depth 9 qt.  
4" Depth 15 qt.  
6" Depth 21 qt.

**TWO THIRDS**  
**12 3/4" X 13 3/4"**  
2 1/2" Depth 6 qt.  
4" Depth 10 qt.  
6" Depth 14.25 qt.

**HALF**  
**12 3/4" X 10 3/8"**  
2 1/2" Depth 4 qt.  
4" Depth 7 qt.  
6" Depth 10 qt.

**HALF SIZE LONG**  
**6 7/16" X 20 3/4"**  
2 1/2" Depth 4 qt.  
4" Depth 7 qt.  
6" Depth 10 qt.

**DOUBLE PAN**  
**25 5/8" X 20 3/4"**

**THIRD**  
**12 3/4" X 6 7/8"**  
2 1/2" Depth 2.63 qt.  
4" Depth 4.5 qt.  
6" Depth 6.5 qt.

**QUARTER**  
**6 3/8" X 10 3/8"**  
2 1/2" Depth 1.63 qt.  
4" Depth 3 qt.  
6" Depth 4.75 qt.

**SIXTH**  
**6 7/8" X 6 1/4"**  
2 1/2" Depth 1.25 qt.  
4" Depth 2 qt.  
6" Depth 3 qt.

**NINTH**  
**4 1/4" X 6 7/8"**  
2 1/2" Depth .63 qt.  
4" Depth 1.25 qt.

Listed sizes and capacities may not be accurate for all stainless steel and plastic food pan brands.