

PATRIOT



HEATED DISPLAY MERCHANDISERS **PT-R60-1C, PT-R60-2C, PT-R60-3C** **USER MANUAL**

WARNINGS

- Fire, injury or death hazard – have this unit installed by a qualified installer in accordance with all state and local codes. Failure to install this equipment properly can result in injury or death.
- Fire hazard – this unit is designed to be used with feet. Do not use without feet installed. Use of this equipment without feet can cause the unit to overheat and cause a fire.
- Fire and burn hazard – fire and burn injuries can occur if this equipment is not used properly. To reduce the risk of injury or death:
 - Do not touch any hot surfaces
 - Plug only into a 3-hole grounded electrical outlet of appropriate voltage
 - Do not immerse unit, cord or plug in liquid at any time
 - Unplug cord from outlet when not in use and before cleaning
 - Do not operate unattended
 - Do not use this unit for anything other than intended use
 - Do not use outdoors
 - Always use on a firm, dry and level surface at least 12” from walls or any other obstruction
 - Do not use if unit has a damaged cord or plug, in the event the appliance malfunctions, or has been damaged in any manner
 - Keep children and animals away from unit
 - Any incorrect installation, alterations, adjustments and/or improper maintenance can lead to property loss and injury. All repairs should be done by authorized professionals only
 - Ensure that the designated power supply is adequate for continual usage and the voltage is correct

*This unit is intended to be used as a merchandiser for hot food in commercial food service operations only. It is not intended for household use.

TO INSTALL

1. Remove all packing material and tape.
2. Clean off any glue or tape residue.
3. Place the unit in the desired position and level using the included feet.
4. Installing doors: Note the longer doors are for the front or sloped side and the shorter doors are for the back or straight side. The doors are fitted with the handles facing outside of the unit. Place the top of the door into the top track and slide the door up to clear and lower into the bottom track.
5. Installing shelves: Place the uprights into the provided slots. Make sure that the longer tab is on top and the flat sides face inwards. Place the shelf supports at the desired locations and position the shelf on these supports.
6. NOTE: The shelf supports and shelves can be positioned level or sloping forward for improved presentation.
7. Plug the unit into a properly grounded electrical supply that matches the data plate rating. Damage to the unit may occur if incorrect power is supplied to the unit.


TO USE

1. Set the thermostat to the desired heat
2. Preheat the unit for approximately 15 minutes, until the unit reaches the set temperature. The light will cycle on and off when the unit has reached the set temperature.
3. Use the toggle switch to operate the light.
4. If moisture is required, fill the humidity pan with 20 ounces of water and monitor the water level

CLEANING – NOTE: To maintain cleanliness and increase service life, the merchandiser should be cleaned daily. Do not immerse the unit in water or any other liquid. If liquid enters the electrical compartment it may cause a short circuit or electrical shock

1. Unplug the unit and allow to cool completely before cleaning
 2. Using a damp cloth or sponge dipped in soapy water
 3. Carefully wipe the unit dry and wait at least a half hour before using the unit.
-

Wiring Diagram for the Heated Displays



One Year Limited Warranty

Patriot warrants its equipment against defects in materials and workmanship, subject to the following conditions:

Patriot is warranted for one year, effective from the date of purchase by the original owner. A copy of the original receipt or other proof of purchase is required to obtain warranty coverage. This warranty applies to the original owner only, and is not assignable.

Should any product fail to function in its intended manner under normal use within the limits defined in this warranty, at Patriot's discretion, such product will be repaired, replaced with a refurbished unit, or replaced with a new unit by Patriot, after defective unit has been inspected and defect has been confirmed. Patriot does not assume any liability for extended delays in replacing any item beyond its control. This warranty does not apply to rubber and non-metallic synthetic parts that may need to be replaced due to normal usage, wear or lack of preventative maintenance.

This warranty covers products shipped into the 48 contiguous United States, Hawaii, and metropolitan areas of Alaska and Canada. Warranty coverage on products used outside the 48 contiguous United States, Hawaii and metropolitan areas of Alaska and Canada may vary.

The following conditions are not covered by warranty:

- Equipment failure relating to improper installation, improper utility connection or supply and problems due to improper ventilation.
- Equipment that has not properly been maintained, damage from improper cleaning, and water damage to controls.
- Equipment that has not been used in an appropriate manner, or has been subject to misuse, neglect, abuse, accident, alteration, negligence, damage during transit, delivery or installation, fire, flood, riot, or act of God.
- Equipment that has the model number or serial number removed or altered.
- Equipment on which the security seal has been broken.

If the equipment has been changed, altered, modified, or repaired without express written permission from Patriot, then the manufacturer shall not be liable for any damages to any person or to any property, which may result from the use of this equipment thereafter.

This equipment is intended for commercial use only and this warranty is void if equipment is used in other than a commercial application.

For warranty and service call 888-585-9440. Please have your model number, serial number and proof of purchase ready.

“THE FOREGOING WARRANTY IS IN LIEU OF ANY AND ALL WARRANTIES EXPRESSED OR IMPLIED INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSES AND CONSTITUTES THE ENTIRE LIABILITY OF ACE. IN NO EVENT DOES THE LIMITED WARRANTY EXTEND BEYOND THE TERMS STATED HEREIN.”